

TWT ST optical adapters

Product Code: [TWT-ST-AM-xx](#)

TWT ST optical adapters



Description

Adapters are installed in optical patch panel, wall or rack type, and optical sockets.

Adapters are pass-through sockets and are used for precise centering of connector tips, and for fixing connectors pressed against each other.

Adapters are available for multi-mode (black caps) and single-mode (yellow caps) connectors.

ST adapter connects two cables terminated with ST connectors. Connector can be installed on a fiber in a cable, a pigtail, or a patch cord.

Model range

TWT-ST-AM-MM	TWT ST optical adapter, MM, simplex
TWT-2ST-AM-SM	TWT ST optical adapter, SM, duplex
TWT-ST-AM-SM	TWT ST optical adapter, SM, simplex

Product descriptions are listed according to the available information at the time of publication. Product specifications can be changed without advanced notification. More detailed and exact information can be obtained from the official partners and distributors of LANMASTER.